

3.4 Golf, Touran, Caddy | Radio Navigation MFD2 | Art.-Nr.: 242.552.MF2.20
Print status: 08.2003 | Ausgabe: Englisch 01.2004

3.4 Golf, Touran, Caddy
*Radio Navigation
MFD2*

About this booklet

This booklet contains important information, tips, suggestions and warnings on using the MFD2 radio navigation system. The other booklets in the vehicle wallet contain further information which you should be aware of for your own safety and for the safety of your passengers.

Ensure that the complete vehicle wallet is always in the vehicle. This is especially important when you lend or sell the vehicle to others.


This manual describes the **scope of vehicle equipment** at the time of publication. Some of the equipment described here will not be available until a later date, or is available only in certain markets.

Illustrations may vary from your vehicle in details. For this reason you should regard illustrations as a general guide.


Directions and positions (e.g. right, left, front, rear) are always relative to the direction of travel of the vehicle unless otherwise stated.


Some sections of this booklet do not apply to all vehicles. If this is the case, a text at the start of the section indicates **to which vehicles it applies**, e.g. "Applies to vehicles with CD changer".

- ® Registered trademarks are marked ®. However, the absence of this symbol does not constitute a waiver of the rights concerning any term.
- ▶ The section is continued on the next page.
- ◀ Indicates the end of a section.

 **WARNING**

Texts with this symbol contain information on safety. They help protect you from accidents and injury.

 **Caution**
Texts with this symbol draw your attention to potential sources of damage to your vehicle.

 **For the sake of the environment**
Texts with this symbol contain additional information on the protection of the environment.

 **Note**
Texts with this symbol contain additional information.

Contents

Quick Reference Guide	2	Destination memory	23
Control elements	2	Parameters for route calculation	26
Display elements on the screen	4	Map and symbol displays	29
Switching on and off	5	Route guidance	34
 		Information and system settings .	36
Radio / CD / Sound	6	Information	36
Radio	6	System settings	37
CD	9	External units	38
Sound, sound focus and volume	14	Calling up external units	38
 		Index	39
Navigation	15		
Overview	15		
Destination entry	18		

Quick Reference Guide

Control elements

This overview will help you to quickly familiarise yourself with the control elements.




Fig. 1 Overview of the control elements

- ① On/off knob (push) and volume control (turn). The volume control will regulate the volume of the audio source currently selected. A column will indicate the volume level. The volume of a telephone conversation can also be regulated using the volume control.
- ② Entries in the screen menus can be made using the menu button. Turn to mark a function or a sub-menu. Press to select a function or a sub-menu.
- ③ Sound and sound centre settings 14
- ④ Left and right of the screen - 5 function keys/station buttons.
 - The term function key is used because the keys have different functions depending on the menu being shown in the display. If the text says, for example, "Press Dest. on map", then press the function key next to where the text "Dest. on map" appears on the screen.
 - Station keys: The upper 6 function keys are used as station buttons in the radio mode. Stations can be stored on these keys. The upper 6 function keys can be

- used to select the inserted CDs in CD changer mode.
- ⑤ Backwards/forwards keys, apply to the *active* audio source
 - press briefly: radio mode: station change; CD mode: changes track
 - press longer: radio mode: manual station selection; CD mode: fast forward/backward search
- ⑥ Switches between day and night display or darkens the screen display 37
- ⑦ Slot for an audio or navigation CD. 9
- ⑧ CD eject button. The ejected CD will be pulled back into the unit if it is not fully withdrawn within 10 seconds.
- ⑨ Set flagged destination. The unit will store the current vehicle position when this button is pressed. When this button is pressed again, the flagged destination will be overwritten if it has not been stored in the destination memory. 18, 23
- ⑩ The traffic jam button calls up the input menu to exclude route sections in a route list or to enter traffic jam information manually 28

¹⁾ Optional equipment

- ⑪ Back to previous menu
- ⑫ Map display when Navigation CD is inserted / Switch to symbol display. 35
- ⑬ Calls up the Navigation main menu. 12
- ⑭ Switches to other auxiliary audio or video units. 38
- ⑮ reserved for additional functions at a later date
- ⑯ CD and CD changer control ¹⁾ 9
- ⑰ Radio menu 6
- ⑱ Call up system settings, traffic reports, position displays 36

⚠ WARNING

Adjust the volume so that you can still hear signals coming from outside the vehicle, such as fire brigade, ambulances or police cars.

⚠ Caution

The screen is not a touch screen. Do not press on the surface. The screen can be cleaned with a soft cloth (and alcohol, if necessary). Do not use solvents such as turpentine or petrol to clean the surface as they will corrode the material. ◀

Display elements on the screen

This section describes the elements seen in the display.




Fig. 2 Display elements

- A The functions or sub-menus shown on the screen can be called up by pressing the function key situated directly next to them. This can also be carried out by first turning the menu knob and then pressing it.
- B The yellow selection box can be moved using the menu knob. It will disappear from the screen if the unit is not used for 30 seconds and will appear again if the menu knob is turned.

- C The selection of the function characteristics, such as **Destin.** or **Overview**, can only be reached by pressing and turning the menu knob.
- D The right part of the status bar contains additional information or the option "back with ESC"
- E Details of the active audio source or navigation status are shown in the centre part of the status bar.
- F The left part of the status bar shows the current menu.

Below the status bar

A light yellow marking indicates which source is active. Press the key beneath it to call up the main menu for this source.

A darker orange marking indicates which source is still active in the background (the radio in this example). Press the key beneath it to call up the main menu for this source.

If the text **CD ?** is displayed in the marking above the **CD** button, the CD inserted in the CD drive cannot be read and may be damaged. ◀

Switching on and off

A safety code made up of four characters must be entered when switching on for the first time.



Fig. 3 Entering the safety code

Switching on/off

- Press the rotary/push knob ⇒ page 2, fig. 1 ①.
- Press the rotary/push knob again to switch the unit off.

Entering the safety code

- The safety code can be found on the unit card.
- Enter the characters by turning and pressing the menu knob ⇒ fig. 3.
- Press **↵** if you wish to change incorrect entries.
- Once the safety code as entered corresponds to the code given on the unit card, press **OK**.

The last menu used and also the last audio source used before switching off will be selected automatically when the unit is switched on again. The MFD2 radio navigation system will be switched off if the ignition is turned off. The unit can be switched on again using the rotary/push knob when the ignition is switched off. It will be switched off automatically after an hour to stop the vehicle battery from running down.

The following text might appear if there is no CD in the CD slot and the safety code has been entered and you have pressed **OK**: **No CD is inserted. Please insert a Volkswagen Navigation RNS MFD2 CD.**

If you do not wish to use the navigation system immediately, you can still select a different audio source by pressing the appropriate button.

Unit card

The code number is printed on a unit card together with the serial number. This card can be found at the front of the vehicle wallet.

The unit card must be kept in a safe place - under no circumstances in the vehicle! Only then will the radio be useless to thieves.

Note

The unit will be blocked for one hour if an incorrect code is entered three times. The code can be entered again after this one hour has elapsed. ◀

Radio / CD / Sound

Radio

Overview

Information is given here on how to select and store stations.



Fig. 4 Radio main menu

The following radio functions are selected via the function keys:

- **[Scan/AS]** – Scans stations or stores those stations with the strongest reception ⇒ page 6, “Scan/AS”,
- **[List/MAN]** – Calls up station list or manual frequency input ⇒ page 8, “Station selection from a list (FM only)”,
- **[Band]** – Sets the waveband and traffic radio, mute function ⇒ page 7, “Setting waveband/Muting”,
- **[Set-up]** – Set-up for RDS functions ⇒ page 9 Settings. ◀

Scan/AS

The stations with the strongest reception are either scanned or stored automatically.



Fig. 5 Autostore AS

Playing stations briefly

- Briefly press ⇒ fig. 5 **[Scan/AS]**.

Autostore on the second memory level (FM2 or AM2)

- Press **[Scan/AS]** for longer than 2 seconds to allocate those stations with the strongest reception in the selected waveband (FM2 or AM2) to the upper 6 function keys.

Autostore for all memory levels (Initial Autostore)

- Press **[Scan/AS]** for longer than 10 seconds to allocate those stations with the strongest reception in all wavebands to the upper 6 function keys. ▶

The selected function will be shown on the screen and can be stopped by pressing **[Scan/AS]** again.

A scan in the FM waveband will play through the list of registered stations. A scan in AM will play all stations with a high quality reception. Each station scan lasts 8 seconds. Press the menu knob or **[Scan/AS]** if you would like to stop at the station currently being played.

Note

Use the function “Initial Autostore” if you are using the unit for the first time or when selecting new stations in the waveband. Any station names on the station buttons will be overwritten. The process of searching for and storing the station names takes a few seconds. ◀

Setting waveband/Muting



Fig. 6 Radio waveband

- Press **[FM1]** or **[FM2]** to receive VHF stations.
- Press **[AM1]** or **[AM2]** to receive medium wave stations.
- When in FM1 or FM2 mode, press **[TP]** to receive traffic information reports.
- Press **[Radio off]** to mute the radio or to switch the mute function off.

The last heard station will be played for the waveband selected. Traffic information reports will be relayed even when the radio has been muted. The TP function must be active for this purpose (yellow column next to the field). When TP is active, the letters TP are lit up in yellow. The increased volume level for the traffic announcement can be lowered by pressing the button **[INFO]**. ◀

- Press **[Band]** in the radio main menu ⇒ page 6, fig. 4 to see the frequencies.

Station selection from a list (FM only)

The MFD2 radio navigation system will automatically compile and store a list of receivable FM stations after the unit is switched on.



Fig. 7 List of stations

- Press **List/ MAN** in the radio main menu ⇒ page 6, fig. 4 to see the stored stations.
- Select a station by turning and pushing the menu knob or by using the right-hand function keys.
- Select a station from the list by turning and pushing the menu knob. You can scroll through several pages of the list using the scroll markers **▲**, **▲**, **▼** and **▼** and confirm your selection by pressing **OK**.

Station selection from memory or by entering frequency

Station selection from memory

- Briefly press button **◀** or **▶** to listen to the stored station.

Station selection by entering frequency

- Press the button **◀**, **▶** ⇒ page 2, fig. 1 **5** or **List/ MAN** for longer than 2 seconds. A station frequency in a yellow frame will appear in the middle of the screen. The frequency will change as long as the buttons **◀** or **▶** are pressed and held.

- For fine tuning, release the button **◀** or **▶** and press the buttons **◀** or **▶** again within 2 seconds to set the exact frequency.

The word **manual** appears on the screen during the frequency input. The search will start in the direction that you have selected in steps of 0.1 MHz (FM) or 9 kHz (AM). In this way you can enter a frequency that you wish to listen to. The frequency can also be altered by turning the menu knob.

Allocating the stations to the station buttons

Stations can be allocated to the buttons to make it easier to select them quickly.

- Press one of the upper 6 station buttons until you hear a signal ⇒ page 2, fig. 1 **4**. The station you are listening to is now stored on the button.

station frequency will appear next to the button. Press one of the buttons if you wish to listen to one of the stored stations.

Note

The memory on a button will be overwritten if a new station is stored there.

RDS settings

Some stations transmit text and information in addition to the station name.



Fig. 8 RDS functions

A tick ✓ will indicate which options have been selected.

Function keys

RDS Name – **Fixed**: Only the station name will be shown. **Variable**: Text information is shown as running text.

RDS Regional – **Auto**: The selected regional programme of a station broadcasting over a wide area will continue to be displayed even when you enter the broadcasting area of another regional programme of the same station.

System settings ⇒ page 37

WARNING

Your attention must, however, always be concentrated on road traffic as an absolute priority. Do not allow yourself to be distracted by the RDS running text.

- Press **Settings** in the Radio main menu ⇒ page 6, fig. 4.

Further text information as running text will not be displayed on the screen, in addition to the station name, for all RDS stations.

CD

Listening to an audio CD



Fig. 9 Main menu CD

Listening to a CD

- Press the ⇒ page 2, fig. 1 **CD** button. If a CD is already in the player, the last played track will be selected. Otherwise the following will appear briefly on the screen: "No Audio CD".

- Insert a standard 12 cm audio CD. The play function will start automatically.

Playing the previous or next track

- Press button **◀** or **▶** briefly.

Fast forward/reverse

- Press and hold button **◀** or **▶**.

Ejecting a CD

– Press **[V]** → page 2, fig. 1 **Ⓚ**.

The number of the track and its length are shown on the screen. **TP** lights up in yellow if traffic reports are to be received and **TMC** indicates whether TMC stations are being received → page 9, fig. 9.

Function keys during the play function:

[CD1]... [CD6] – Selects the corresponding CD in the CD changer if connected ²⁾.

[Int. CD] – Selects the CD that is in the unit.

[Scan] – All tracks on the CD will be played for 8 seconds at a time.

[Mix] – The tracks on the CD will be played in a random order.

[System settings] → page 37

⚠ WARNING

The CD player is a class 1 laser product. If it is opened, or is faulty or damaged, there is a risk of invisible laser beams escaping from the unit. The CD player contains no parts that have to be serviced. Any repair work that needs to be done should, therefore, be carried out by Volkswagen Service® exclusively.

⚠ Caution

• Only 12 cm standard CDs should be used, not 8 cm single CDs. Only round CDs should be inserted in the CD slot. "Special shape CDs" cannot be played and they will damage the CD player.

• Slide the CD with the printed side up into the CD slot up to the point where it is drawn in automatically. Hold the CD at the sides. Avoid leaving fingerprints on the CD. Clean the CD with a dry, lint-free cloth. When doing this, wipe the CD from the centre outwards. Do not clean the CDs using alcohol or solvents. Do not place the CDs near heat sources or in the direct sunlight. Do not write on the CDs and do not attach stickers to them.

i Note

- The upper 6 function keys are only active if a CD changer has been connected.
- CD-R and CD-RW formats can also be played, depending on the quality of the blanks.
- If the text **CD ?** is displayed in the small marking above the **[CD]** button, the CD inserted in the CD drive cannot be read and may be damaged. ◀

²⁾ Optional equipment

Applies to vehicles with CD changer

CD changer

An external CD changer can be connected in addition to the internal CD drive of your MFD2 radio navigation system.




Fig. 10 CD changer

- LOAD**
 - Use the **[LOAD]** button to prepare the next free CD slot for loading.
- The LEDs above the buttons indicate the status of the corresponding CD slot.
 - **CD slot empty**; the LED is off.
 - **CD slot being prepared**; the LED flashes slowly.
 - **CD slot ready**; the LED flashes quickly.
 - **CD slot is loaded**; the LED is lit permanently.
- CD slot

- Push the audio CD with the printed side facing the front passenger side into the CD slot until it is automatically pulled in.
- [EJECT] Ejecting a CD**
 - The current CD is ejected from the player.
- [1]–[6]**
 - These buttons can be used to select one of the six CD slots after you have pressed **[LOAD]** or **[EJECT]**.

i Note

You might not be able to play CDs with copy protection or CD-Rs and CD-RWs. ◀



Applies to vehicles with CD changer

Operating the CD changer

Up to six audio CDs can be inserted in the external CD changer. There is no need to fill all the slots in the CD changer.

Loading CDs

- Lift the centre armrest between the front seats.
- Press **LOAD** ⇒ page 11, fig. 10 ①. The LED ② above the next free CD slot will start to flash slowly. It shows which CD slot is being prepared.
- Wait until the LED starts to flash quickly.
- Now push a 12 cm standard audio CD with the printed side facing towards the front passenger side into the CD slot until it is automatically pulled in.

Selecting a CD on the CD changer

- In CD mode you can select the CDs in the CD slots of the CD changer directly by pressing buttons ① to ⑥. If a CD slot contains a CD, the LED ② above the button will light up.

Ejecting CDs

- If you wish to eject the CD which is being played in the CD changer, press ⇒ page 11, fig. 10 **EJECT**.
- If none of the CDs in the CD changer is being played, press **EJECT** and buttons ① to ⑥ to select the CD you wish to eject.

Fast loading

Press and hold ⇒ page 11, fig. 10 **LOAD** for longer than three seconds to quickly load all free CD slots.

All free slots in the CD changer will be prepared automatically and can then be loaded one after another.

Ejecting all CDs

In order to eject all of the CDs from the CD changer, keep the **EJECT** button pressed for longer than 3 seconds.

All CDs in the CD changer will then be ejected one after the other.

Ejecting / loading specific CDs

First press the **LOAD** button to load a free CD slot, or **EJECT** to eject a CD from a loaded CD slot. Then use the buttons ① – ⑥ to select the corresponding CD slot.

CD changer and the radio display

A loaded CD slot will be indicated on the CD changer by a permanently lit LED ②.

In the MFD2 radio navigation display the text **NO CD** shows you which CD slots are empty in CD mode. Loaded CD slots are indicated in the display with **CD** and the corresponding number.

CD ERR is shown in the display if the CD changer cannot read a CD that has been loaded.

⚠ WARNING

The CD changer is also a class 1 laser product. If it is opened, or is faulty or damaged, there is a risk of invisible laser beams escaping from the unit. The CD changer contains no parts that have to be serviced. Any repair work that needs to be done should, therefore, be carried out by Volkswagen Service® exclusively.

⚠ Caution

- Always insert CDs with the printed side facing the front passenger side.
- Please ensure that you do not drop the CD while removing it from the magazine.
- Only 12 cm standard CDs should be used, not 8 cm single CDs. Only round CDs should be inserted in the CD slot. "Special shape CDs" cannot be played and they will damage the CD player. ◀



Applies to vehicles with CD changer

Playing a CD from the CD changer

How to use the MFD2 radio navigation system to select a CD in the CD changer.



Fig. 11 CDs currently in the changer

- Use the function keys **CD1** to **CD6** to select a CD from the changer.

Uneven road surfaces and strong vibrations may cause the CD to jump. The CD play function should be switched off in this case. ◀

Sound, sound focus and volume

This section describes how the sound character and the volume of different sound sources can be set individually.



Fig. 12 Sound main menu

– Press the button => page 2, fig. 1 to open the Sound main menu.

Function keys in Sound main menu:

or – Treble or Bass settings => fig. 12.

– Volume setting for the mid-range frequencies.

– Sound focus setting left / right.

– Sound focus setting front / rear.

– Opens the volume set-up where individual volume settings can be made for the different audio sources => fig. 13.

Function keys in the volumes set-up function:

– The setting for the sensitivity of the speed-dependent volume adjustment (GALA). The volume of the audio source will be increased automatically by GALA as the road noise increases at higher speeds. The volume will be in-



Fig. 13 Volume settings

creased more the further the control is set towards the right.

– Minimum volume for traffic announcements.

– Minimum volume for telephone conversations.

– Minimum volume for navigation system announcements.

– The traffic announcements are muted as long as a yellow bar can be seen next to the function key.

– Sets the minimum volume for when the unit is switched on.

Note

By pressing buttons => page 2, fig. 1 , and status button at the same time, you can reset the MFD2 radio navigation system to the factory settings. The message, **Default settings being made. Please wait!** is shown. ◀

³¹ Vehicles with a sound system

Navigation

Overview

How does the navigation system work, and how is it operated?

An optimal route is defined using sensors, satellites and traffic reports and the driver is then guided to his or her destination.

The current vehicle position is determined using a system of satellites (GPS - Global Positioning System). Sensors in the vehicle measure distances that have been driven. Measured values are compared using the detailed map material on the navigation CD and corrected with the assistance of TMC traffic announcements as necessary. An optimal route to the destination is determined in this way.

Navigation announcements and direction arrows shown on the screen and in the combi-instrument guide you safely and conveniently to your destination. You can drive to a given address in towns you are unfamiliar with, or drive to the nearest garage or be guided to a hotel.

In this chapter, answers can be found to the following questions:

- What rules do I have to keep to when using the navigation system? => page 15, "Safety"
- How do I use the navigation CD? => page 16, "The navigation CD"
- Can I listen to music when using the navigation system? => page 16, "General notes"

Safety

The navigation system determines the position of the vehicle, the direction and distance and the route to a selected destination without taking traffic regulations into account. Navigation recommendations are given as announcements by the system. Direction arrows are also shown on the screen. The destination is entered when the vehicle is stationary. The route guidance function is designed for cars and is thus unsuitable for larger commercial vehicles.

- What happens if I leave the recommended route? => page 16, "General notes"
- Can a navigation announcement be repeated? => page 35, "Announcement of navigation recommendations"
- How does the MFD2 radio navigation system respond when driving in an underground car park or a tunnel? => page 16, "General notes"
- How do I enter destinations? => page 18, "Destination entry"
- How can I enter garages, restaurants or hotels as destinations? => page 21, "Special destinations close to the address"
- Can I store destinations in a memory? => page 23, "Destination memory"
- What parameters can I set for route calculation? => page 26, "Parameters for route calculation"
- What can I see on the screen? => page 29, "Map and symbol displays"
- Can I stop the route guidance function before I reach my destination? => page 34, "Route guidance" ◀

WARNING



- Please observe the laws of road traffic legislation when following the recommendations made by your navigation system.
- Route guidance is subject to constant changes despite the information about one-way streets, pedestrian zones etc. stored on the navigation CD. Information on traffic lights, stop and right of way signs, parking and stopping restrictions as well as lane constrict-

WARNING (continued)
 tions is not included in the navigation system. Traffic signs and legislation always have priority over the recommendations made by the system.

WARNING (continued)
 • Adjust your speed to suit road traffic conditions and also weather and visibility conditions. Do not drive faster in fog, for example, if the navigation system tells you to do so. ◀

The navigation CD


Inserting the navigation CD

- Press the button  ⇒ page 2, fig. 1  to eject any CD in the CD slot.
- Remove the CD and insert the navigation CD with the written side facing up.
- Push the CD into the slot until the MFD2 radio navigation system pulls it in. The program stored on the navigation CD is loaded. Do not remove the navigation CD before the loading process is finished.

The navigation CD contains a digitalised road map. The extent to which small villages, streets and house numbers are contained on the CD depends on the CD version.

The content of the CD is constantly being updated. You will receive information on new updates at your next Volkswagen Service®. You will need a new navigation CD for every country that you travel to.

Note

If the text **CD ?** is displayed in the small marking above the  button, the CD inserted in the CD drive cannot be read and may be damaged. ◀

General notes

You can continue to listen to the radio or CD (via the CD changer) whilst you are being guided to your destination.

When entering an address (town, street), only those letters or symbols which make up a logical entry will be presented. A list of possible names will be shown. Do not forget to enter the blank space in names made up of more than one word, such as High Wycombe.

The route will be recalculated if you leave or disregard the route that was originally calculated. This process takes only a few seconds.

The last announcement made can be repeated. The volume of a navigation recommendation can be changed whilst it is being made.



A variety of different information on the route can be called up during active route guidance. The scroll function can be used to page through lists shown on the screen, either line by line or page by page.

If the display **Off Road** appears on the screen, it means you are located on a non-digitalised street, e.g. on a farm track. The GPS satellites will not be able to reach your aerial when you are in a tunnel or underground garage, meaning that the unit orientates itself via the wheel sensors. If you try to carry out a route calculation in this situation you may hear the announcement: "You are located on a non-digitalised street". Drive on until the display **Off Road** disappears. ◀

Main menu - Navigation



Fig. 14 Main menu Navigation

- Press the key  to enter the Navigation main menu ⇒ page 2, fig. 1 .

Function keys in the Navigation main menu

Start route gd. – Starts route guidance to the entered destination. Pressing this button again will stop the route guidance function ⇒ page 34, "Route guidance".

Destination – Field for entering your destination ⇒ page 18, "Destination entry".

Stopover – Field for entering a stopover destination. A stopover destination is entered in the same way as a destination. A stopover destination is deleted from the screen as soon as it has been reached. It will, however, remain in the memory **Last dest.** ⇒ page 18, "Destination entry". If the stopover destination is reached, you will be informed that you have reached your destination, and route guidance to the final destination is started automatically. If the stopover destination is not reached exactly, e.g. because it is not located directly on a road, you will be informed that you have reached the destination area. Route guidance to the next destination is not started automatically.

Route opt. – Defines the parameters for route calculation ⇒ page 26, "Parameters for route calculation".

Settings – Enter your location manually or start a demonstration ⇒ page 27, "Settings". ◀

Destination entry

Starting destination entry

Two addresses can be entered for the route calculation; the address of the destination and the address of the stopover destination.



Fig. 15 Destination

- Press the key **[NAVI]** to enter the Navigation main menu **[1]** → page 2, fig. 1.
- Press **[Destination]** or **[Stopover]** in the Navigation main menu → page 17, fig. 14 to select between the destination entry options.

You will see a message that states that a destination has not yet been defined if the destination is being entered for the first time. The last used destination will be displayed if a destination has already been entered.

There are various methods of entering a destination or a stopover destination. The procedure for entering the stopover destination is the same as for the destination.

[New Address] – Enter the destination using town and street names → page 19, "Entering a new address (town, street, house number)".

[Last dest.] or **[From dst. mem.]** – Select a destination from a list of destinations that have already been stored → page 20, "Last destinations".



Fig. 16 Stopover destination

[Special dest.] – Enter a restaurant, a garage, an airport, border crossing etc. as a destination → page 21, "Special destinations close to the address".

[To flagged dest.] – The position where you were located when you last pressed button **[M]** → page 2, fig. 1 **[1]** is entered as the destination.

[Dest. on map] – Mark your destination on a map using a crosshair → page 22, "Destination on the map".

[Position dest.] – Enter the longitude and latitude of a destination → page 22, "Position destination".

[Travel guide] – Select a destination from the travel guide. A travel guide is only available on certain navigation CDs. Further search functions depend on the content of the travel guide.

[Edit memory] – Store, delete or edit destinations in the destination memory → page 23, "Destination memory".

[Del. stopover] – Deletes the entered stopover destination. **[←]**

Entering a new address (town, street, house number)



Fig. 17 Entering a new address

- Press **[Town]**, **[Street]** or **[House number]** to enter the name using the letter selection function.
- Enter the letters or numbers by turning and pressing the menu knob.
- You will see a list of names or numbers in the lower half of the screen. Press **[OK]** to enter the list.
- Select a name from the list by turning and pushing the menu knob. You can scroll through several pages of the list using the scroll markers **[▲]**, **[↓]**, **[▼]** and **[↑]** and confirm your selection by pressing **[OK]**.
- Press **[Close to addr.]** to select a special destination close to the destination address (town, street etc.) that you have already entered.



Fig. 18 Entering a town name

[←] and **[→]** mark characters and **[X]** deleted characters.

[i] will display language-specific characters as necessary.

The term "Town" is used regardless of how many people live there. Both a village of 100 inhabitants and a city with 1 million are named as towns. A list of names to choose from will appear for town names which are used more than once. The system will automatically switch to street entry after town entry and then to house number entry. The centre of the town will be offered as a destination if the town is so small that none of the streets have been digitally mapped.

The keys **[Street]** and **[House number]** will not be active if a town name has not been entered.

[i] Note

Enter an intersection and house number as described. **[←]**

Last destinations

The last destinations that have been used will be stored automatically.



Fig. 19 Last destinations

Making a selection from the last destinations

- Press ⇒ page 18, fig. 15 (Last dest.) to make a selection from the list of the last used destinations ⇒ page 18.
- Turn the menu knob to make a selection from the list of the last used destinations ⇒ fig. 19. Press **[i]** to make an address fully visible if it cannot be read fully.
- Press the menu knob to select the address marked in yellow. The Navigation main menu will appear with your selected address after a few seconds.



Fig. 20 Deleting last destinations

Deleting the list of last destinations

- Starting in the Navigation main menu ⇒ page 17, fig. 14 press the following function keys: (Destination), (Edit memory) and (Delete last dest.).
- Select (Cancel) or (Delete) when confirmation is asked for. If you select (Delete), all of the last destinations, including the current destination, will be deleted.

The addresses collected in the **Last dest.** memory can only be deleted all at once, not individually.

A total of 14 last destinations can be stored in the memory. A destination will not be stored in **Last dest.** until route guidance has started. If you are not able to store any more destinations, the destination memory is full. Delete either the **last destinations** memory or destinations from the destination memory ⇒ page 25. ◀

Addresses from the destination memory



Fig. 21 Complete destination address

- Press ⇒ page 18, fig. 15 (From dest. memory) to see a list of the stored destinations.
- You can move a yellow column by turning the menu knob. Press **[i]** to make an address marked in this way fully visible if it cannot be read fully.
- The address marked in yellow will be activated if the menu knob is pressed. The Navigation main menu will appear with your selected address after a few seconds.

You will be shown a message if the destination memory is full. Some of the destinations should then be deleted manually. ◀

Special destinations close to the address

Special destinations close to the destination can be selected from a list.



Fig. 22 Special destinations close to the address

- Press ⇒ page 19, fig. 17 (Close to addr.) to select a special destination close to the destination address (town, street etc.) that you have already entered.

Special destinations of the same category, e.g. restaurants, will be displayed in a list. The nearest destination will be shown in the first position.

Note

- If you have not changed your destination address entry, the area close to this last destination will be analysed and the special destinations there will be listed.
- The type and number of special destinations will be determined by the content of the Navigation CD. ◀

Destination on the map

A crosshair can be used to mark a destination on the map.




Fig. 23 Destination on map

- Press ⇒ page 18, fig. 15 (Dest. on map).
- Use the right-hand function keys to move the crosshair to your required destination.
- Use (P) or (P) to alter the scale to suit your search strategy ⇒ page 30, "Changing the scale".

Note

The next section of the map will be shown after a few seconds when the crosshair is moved to the side of the screen. ◀

Position destination

A destination can be entered using the exact coordinates for longitude and latitude.




Fig. 24 Position destination

- Press ⇒ page 18, fig. 15 (Position dest.) if you want to enter your destination using coordinates.
- Turn the menu button to set the figure.
- Press the menu knob. The yellow square will disappear and a yellow frame appears.

- Move the yellow frame to the arc minutes and then to the hundredth of an arc minute.
- Press the menu knob again and enter the required figure.

Germany, for example, lies between 47° and 54° northern latitude and 6° and 14° eastern longitude. The route guidance function cannot be started if the figures entered are not within this area and the navigation CD for Germany has been entered. Use the following data to estimate the position of your location:

for latitude, 1° corresponds to approximately 111 km, 1 arc minute approximately 1.85 km and 1 hundredth of an arc minute approximately 18.5 m

for longitude, 1° corresponds to approximately 69 km, 1 arc minute approximately 1.15 km and 1 hundredth of an arc minute approximately 11.5 m

Note

If you set the longitude higher than 180° or lower than 0°, the E will be replaced by a W (western

longitude). Latitudes can be set from 90°N via 0° to 90°S and back only. ◀

Destination memory

Storing destination, stopover destination, flagged destination or location

Storing the different destinations means giving them a name and storing them in the MFD2 radio navigation system.



Fig. 25 Editing the memory



Fig. 26 Storing the destination

- After entering a new address, press (starting from the Navigation main menu) ⇒ page 17, fig. 14 (Destination), (Edit memory).
- Press (Store dest.) to open the letter input menu.
- Enter a name for your destination, e.g. "Mr Smith" or "Holiday home".

- Press (OK) to save the destination with the name.

The destination can now be called up from the memory as you need it. The name should be short and clear. You can also use the names that are suggested.

You enter the destination name in the same way used for entering a street name ⇒ page 19. ◀

Renaming destination



Fig. 27 Renaming a destination

- Starting in the Navigation main menu ⇒ page 17, fig. 14 press (Destination) followed by (Edit memory) then (Rename destination).
- Turn the menu knob to move the yellow bar to the name that you wish to change.
- Press the menu button to call up the entry function for the letters.
- Edit the name ⇒ page 19.
- If, however, you wish to keep the original name and not the new one, press the (ESC) button ⇒ page 2, fig. 1 (1). Your alterations will not be stored. ◀

Sorting destinations

The various different addresses in the destination memory are stored chronologically according to their entry date and can be sorted at a later date according to your requirements.



Fig. 28 Sort: Select

- Starting in the Navigation main menu ⇒ page 17, fig. 14 press (Destination) followed by (Edit memory) then (Sort destinations).
- Turn the menu knob to move the yellow bar to the destination that you would like to move to another position.



Fig. 29 Sort: Store

- Press the menu knob. **Sort: Store** now appears at the top of the screen. You can now move the address up or down by turning the menu knob.
- Press (OK) to store the address in the new position. **Sort: Select** now appears again at the top of the screen.

- Press the (ESC) button ⇒ page 2, fig. 1 (1) The other destinations will be moved down if you move a destination to a position that is already occupied. ◀

Deleting individual destinations or the entire destination memory

You can, in contrast to the "last destination" memory, delete individual destinations from the destination memory.



Fig. 30 Deleting destination memory

Deleting an individual entry

- Starting in the Navigation main menu ⇒ page 17, fig. 14 press (Destination) followed by (Edit memory) then (Delete destination).
- Turn the menu knob to move the yellow bar to the destination that you would like to delete and then press the menu knob.
- When asked for confirmation, press (Delete). If you do not wish to delete the destination, press (Cancel).



Fig. 31 Selecting entry to delete

Deleting the entire destination memory

- Starting in the Navigation main menu press (Destination) followed by (Edit memory) then (Clear dest. memory).
- When asked for confirmation, press (Delete). If you do not wish to clear the destination memory, press (Cancel). ◀

Parameters for route calculation

Route options



Fig. 32 Route options

– Press **Route opt.** in the Navigation main menu ⇒ page 17, fig. 14.

A short route might be quicker for your purpose in larger towns or cities where there are a lot of traffic jams. Route options can be altered whilst the route guidance function is active. The changed parameters will be used as a basis for the calculation of the remaining journey.

Function keys in the route option menu

Route

- **Fast or Short:** Determines whether a fast or short route should be calculated.
- **Dynam.:** Dynamic route guidance responds to traffic reports broadcast by TMC stations. This function will automatically guide you round traffic jams or blocked roads.

Motorway, **Ferry** or **Toll** – Determines whether motorways, ferries or toll roads should be used. These options will, however, be used for calculation if there is no other logical route to the destination (e.g. an island is to be used without using a ferry).

By default – Stores the selected settings for future route guidance usage.

Dynamic route guidance

An announcement that there are traffic jams on your route will be made if a traffic jam is regis-



Fig. 33 Symbols for traffic problems

tered. You will also be warned directly before the traffic jam itself.

Once the dynamic route guidance function has been activated you will be informed that the route is being recalculated due to traffic problems if any have been registered.

Traffic problems are indicated by a symbol on the map:

- ▲ Traffic jam ⇒ fig. 33 A
- ▲ Slow-moving traffic ⇒ B
- Road closed ⇒ C

The navigation system will calculate the quickest possible route when the dynamic route guidance option is active. The system might well guide you through a traffic jam if the diversion would be longer.

Note

- The dynamic route guidance option will only function if you are receiving at least one TMC radio station.
- The MFD2 radio navigation system will automatically look for a new TMC station if you leave the reception area of the one you are using. The station you are listening to, however, does not have to be a TMC station.
- The dynamic route guidance option will always use motorways, ferries and toll roads. ▶

- The quality of the dynamic route guidance depends on the information contained in the traffic announcements. The radio stations

broadcasting this information are responsible for the content. ◀

Settings

The vehicle position can be entered manually and you can then start a demonstration journey.



Fig. 34 Settings in the Navigation main menu

Entering your position

– Press **Settings** in the Navigation main menu ⇒ page 17, fig. 14 to enter the vehicle position.

– Press **Position location**. The entry window for the town appears. The entry for the street is made after you make your entry and confirm it with **OK**. After confirming the name of the street you will see a list of the streets which have an intersection with the named street.

– Select the intersection and confirm your choice by pressing the menu knob.

– Now enter your position either before or after this intersection in metres and also enter the direction of travel using the points of the compass.

– Confirm your entry by pressing **OK**. The screen display will return to the Navigation main menu.



Fig. 35 Position settings

Entering your position on the map

– Press **Settings** and then **Position map** to see your set position on the map. The scale of the map can be altered using the two top left-hand function keys.

– Press the **ESC** button ⇒ page 2, fig. 1 ① twice to return to the Navigation main menu.

Starting the demonstration

– Press **Demo** and then select **active**. The navigation system is activated.

– The MFD2 radio navigation system will now travel along the route virtually from start to finish if the route guidance function is started. You can listen to announcements and look at displays.

The navigation system will need some time for an exact definition of your position if you have transported your vehicle using the train or a ferry. Your position can be entered manually if the automatic definition is not successful. ▶

The manual position input can be used to calculate a route between any two points regardless of where the vehicle is actually located. ◀

Manually excluding stretches of the journey

Stretches of the journey ahead and/or parts of the route list can be blocked manually.



Fig. 36 Blockage and traffic jam

Menu for blocking and traffic jams

– Press the traffic jam button ⇒ page 2, fig. 1 ⑩ if you want to block a stretch of the route ahead.

Entering traffic jam information

- Press ⇒ fig. 36 [Congest. ahead].
- Turn the menu button to enter the length of the traffic jam.
- Press the menu knob. The display will be switched to the map. You will hear an announcement that the route is being calculated. The excluded stretch of the route will be shown as a dotted blue line on the map.
- Press **Cancel exclusion option** to include this stretch of the route in the navigation option again.

Blocking part of the route list

– Press [Enter exclusion]. You will see a part of your route list.



Fig. 37 Blocking a stretch of the journey

- Using the menu knob, move the yellow bar to a line that starts with + or -. The stretches of the route are broken down into sections and can be opened or closed by pressing [▶] or [◀].
- Turn the menu knob to move the yellow bar to the start of the section that you wish to exclude from the navigation. Press the menu knob. The entry is now red.
- Turn the menu knob. All stretches of the route that are blocked will appear in red. Press the menu knob once you have marked the route section in question. The display will be switched to the map. You will hear an announcement that the route is being calculated. The excluded stretch of the route will be shown as a dotted blue line on the map.
- Press [Cancel exclusion option] to delete the blocking function.

You will be guided through a blocked area if there is no logical alternative to travelling through it.

Note

If you use a map CD which contains only major routes, you will have less alternative routes than

if you use a CD which contains minor roads. To ensure that you do not have to make unnecessary detours, you should use a map CD containing all roads when you wish to be guided around congestion on the route. ◀

Map and symbol displays

Information in the map and symbol displays

Information on the route will be shown in the map or symbol displays if the route guidance function is active.



Fig. 38 Map display

- Press the [MAP] button ⇒ page 2, fig. 1 ⑫. The screen will switch between map and symbol displays.

Map display

- ① Autozoom active (👁️ in yellow). The scale of the map will, for example, be larger for motorway driving and more detailed when making a turn.
- ② Journey time or arrival time.
- ③ Distance to destination or stopover.
- ④ Road name.
- ⑤ Vehicle position. The black arrow points in the direction of travel. The route ahead is shown as a blue line.




Fig. 39 Symbol display

- ⑥ Route options and TMC.
 - If the dynamic route guidance option is active, the horizontal arrow is shown with a D, and blocked roads are shown as ⚫.
 - TMC: The number of TMC reports received is shown by the white dots.

- ⑦ Map scale
- ⑧ North.

Traffic problems are indicated by a symbol on the map:

- ⚠️ slow-moving traffic
- 🚧 traffic jam
- ⚫ closed road

Symbol display

- A The number of GPS satellites.
- B Route option (in this example dynamic route guidance D).
- C Arrival time or journey time.
- D Distance to destination or stopover.

- E Turn arrow, above it the name of the street you are turning into.
- F Current road
- G The proximity bar shows how far away the turning point is. The distance to the next change of direction will be shown in the display after you have turned. ◀

Changing the scale

You can choose from a total of 13 different scales.



Fig. 40 Changing the scale

– Press [F] or [G].

[F] – More details. A scale display appears in the top left-hand corner when the button is pressed => fig. 40

[G] – Large overview. A scale display appears in the top left-hand corner when the button is pressed.

The selected scale will be shown once the menu knob is pressed or after 3 seconds. ◀

Changing display options

The map type and display can be selected, although some settings cannot be seen until active route guidance has started.



Fig. 41 Display options

– Press => page 29, fig. 38 [E] to change the display options.

Map type

- Location – Shows your position on the map.
- Destin. – Shows the area surrounding your destination.
- Overview – Shows the entire route.

The map will always be shown in the direction North at the top if you have chosen the map type Overview or Destin. In the map display option auto, a detail map (up to 2 km per cm) with the direction of travel at the top and an overview map (as of 5 km per cm) with North at the top will be shown. ▶

Alignment

- auto – The system selects the map display
- Travel – The display always adjusts to the direction of travel.
- North – North is always at the top of the display.

Autozoom

- high – Smaller scales are given priority for the automatic scale selection.

- low – Larger scales are given priority for the automatic scale selection.

The settings for Autozoom will only take effect if [B] is pressed in the map display => page 29, fig. 38 [A].

Time format

- Travel t. – Shows the remaining travel time
- Arrival – Shows the estimated arrival time => page 29, fig. 38 [B]. ◀

Traffic reports display

Short texts of traffic reports that have been received can be called up from a list.



Fig. 42 Traffic reports

– Press [E] in the map display => page 29, fig. 38.

– Or press [INFO] and [Travel info].

– Turn the menu knob to move the yellow bar to the traffic report you are interested in.

– Press [I] to see the full text of the traffic report. ◀

Moving the map section using the crosshair




Fig. 43 Crosshair

– Press [B] in the map display => page 29, fig. 38 to call up the shift function.

– Using the right-hand function keys or by turning/pressing the menu knob, move the the crosshair to the destination of your choice.

– Use the scale modifications to adapt the display to suit your requirements => page 30.

The neighbouring map section will be displayed if you move the crosshair to the side of the screen. This procedure can take some seconds. ◀

Augmenting map contents

A range of symbols can be used to display additional map content.



Fig. 44 Map contents

- Press **[M]** in the map display ⇒ page 29, fig. 38.
- Turn the menu knob or use the right-hand function keys to move the yellow bar to the map detail you are interested in.
- Press the menu button or **[OK]**. A "tick" will appear next to the map detail.

Note

You can lose the overview of the map if too many map details are selected. ◀

Route list

The route list is a list of all route sections which will be travelled through with active route guidance.



Fig. 45 Route list from the map

- Press **[M]** in the map display ⇒ page 29, fig. 38 to see the route sections of your current journey.

The route list is updated during the journey. It shows the roads that you have not yet reached. Route sections that you have already travelled will be deleted from the route list.

Note

It takes some seconds after route guidance has started for the route list to be compiled so that it can be displayed. ◀

Position display

The current information on the position of the vehicle is shown here.



Fig. 46 Position display

- Ⓐ GPS status (number of satellite receptions, positioning mode) including the direction and distance to destination (with active route guidance).
- Ⓑ Direction of travel
- Ⓒ Altitude (GPS altitude). If too few satellites are received to calculate the altitude, the display is grey.
- Ⓧ GPS position (longitude)
- Ⓨ GPS position (latitude)

The direction of travel is shown in degrees and also in the form of a compass.

The GPS status shows the number of satellites as dots and also shows the positioning mode (NO FIX, 2D FIX, 3D FIX).

- **NO FIX** – The GPS reception is not sufficient to fix the position of the vehicle.
- If the position definition for **NO FIX** is only possible using the wheel sensors (underground garage etc), the GPS coordinates will be displayed in grey. The GPS coordinates will no longer be shown following a long distance with **NO FIX** in the display or if it is not possible to determine the position.
- **2D FIX** – The horizontal position of the vehicle can be determined, but not the altitude (altitude display is grey).
- **3D FIX** – Position and altitude can be determined.

The altitude given is accurate to ±15 m at altitudes between 0 m and +5000m. The system will be less accurate if the GPS reception is bad or weather conditions are poor.

The direction to the destination is shown in the form of a marking outside the compass. If the destination is not in the area displayed by the compass (i.e. to the side or behind the vehicle), the marking is shown as an arrow to the side in question. ◀

Route guidance

Starting/stopping route guidance



Fig. 47 Ending route guidance

– Press **[Start route guid.]** You will hear an announcement that the route is being calculated. The MFD2 radio navigation system will automatically switch to the map display.

- Press the button **[NAVI]** to return to the Navigation main menu.
- Press **[Stop route gd.]** if you wish to stop the route guidance function before you have reached your destination.

The route guidance function can only be started if you have already entered a destination.

Note

- You should drive on a bit further if the system makes the announcement that you are not on a digitalised street before starting route guidance. The unit might have to orientate itself using the next main road.
- The active route guidance function will be interrupted if a stopover destination is entered. ◀

Announcement of navigation recommendations

Navigation recommendations are made as spoken announcements and also in the display.




Fig. 48 Map display

- Press the **[MAP]** button => page 2, fig. 1 12.
- Press **[CL]** if you want to hear the current navigation recommendation => ⚠.

You will hear the first announcement after the route has been calculated. Up to three announcements will be made before a turn has to be made to ensure that you are informed in time. A proximity bar will be shown in the display on the right-hand side of the turn arrow shortly before the last announcement is made. The proximity bar shows how far away the turning point is. The distance to the next change of direction will be shown in the display after you have turned.

You will receive a recommendation for a lane on roads with more than one lane that then separate off in different directions.

You will also be told which exit to use off a roundabout before you enter it, e.g. that you should leave by the second exit. This announcement will then be repeated when you are travelling round the roundabout.

An announcement will be made when you reach your destination. You will be informed that you have reached your destination if it is on a digital-



Fig. 49 Symbol display

ised road. If it is not on a digitalised road, you will be informed that you have reached the destination area. The latter may occur if you have entered the destination using coordinates and it is not on a road.

WARNING

You, as the driver, must concentrate on the spoken announcements and also on the traffic around you. The recommendations made on the basis of the information on the CD may differ from what you actually see due to incomplete data or a different road layout (e.g. due to road works). Please keep to traffic regulations and ignore the navigation recommendations if necessary.

- Traffic signs and legislation always have priority over the recommendations made by the system.
- Please observe the important safety warnings => page 15, "Safety".

Note

The direction arrow in the map display will be faded out if you are travelling in the same direction for an extended period. ◀

Information and system settings

Information

The MFD2 radio navigation system stores text and spoken announcements made by the radio stations and draws up a route list whilst the route guidance function is active.




Fig. 50 Info main menu

– Press **[INFO]** button ⇒ page 2, fig. 1 **(18)** to enter the Info main menu.

Function keys in the Info main menu

The function keys **TIM messages**, **Travel inform.**, **Route list** and **TMC stations** are grey if no further information is available.

[TIM messages] – Plays back recorded traffic reports (Stop by pressing **[ESC]** ⇒ page 2, fig. 1 **(11)**).

The TIM messages are stored chronologically. The latest message is at the top of the list. The selection bar will spring automatically to the next message once the first message has been played. The system will return to the main menu after the last message has been played and will then reactivate the audio source that was being used. All of the messages will be played if another menu button, e.g. **[RADIO]** is pressed whilst a TIM message is being played. The oldest announcement will be overwritten if the memory is full.

[TMC stations] – Displays a list of receivable TMC stations. Select a station whose traffic reports should be played if you happen to be listening to another radio station. A different station will be



Fig. 51 Setting the TIM time

chosen automatically if the selected station can no longer be received.

[Travel inform.] – Displays a list of the latest traffic reports ⇒ page 31.

[System settings] ⇒ page 37

[System info] – Displays the software version installed in the MFD2 radio navigation system.

[Route list] – Displays a list of the streets on the route to the destination. Use the menu knob to page through the street lists that are on your navigation route. Press **[I]** if an entry is not fully displayed.

[Position display] ⇒ page 33

[Settings]

- **TIM time 1** and **TIM time 2**: Two different departure times can be entered here, e.g. 7.00 a.m. and 5.30 p.m. The unit will start recording traffic reports 1.5 hours before your departure. This means that you will have up to date traffic information right from the start of your journey.

- **TIM Standby** – Traffic reports will be recorded for two hours after you have switched off the unit.

Note

The list of announcements cannot be opened whilst a traffic announcement is being made, as it is also being recorded. ◀

System settings

In the system settings menu, you can select different languages for the displays and spoken announcements, and adjust the screen brightness.



Fig. 52 System settings

– In the Info main menu, press ⇒ page 36, fig. 50 **[Syst. settings]** to see which settings can be made. You can also call up the system settings from the Radio main menu by pressing ⇒ page 6, fig. 4 **[Settings]** or from the CD main menu ⇒ page 9, fig. 9.

Function keys in the Settings menu

[Language] – Shows a list of available languages for display texts and spoken announcements. Select

a language by turning and pressing the menu knob. You will see a display text in the chosen language. Do not press any further keys until the loading sequence is finished.

[Day/Night] – You can set the screen brightness to be adjusted to suit the light conditions when the headlights are switched on.

- **auto**: The night display will automatically be selected when the headlights are switched on.
- **manual**: Press **[☀]** ⇒ page 2, fig. 1 **(13)** to switch between the day and night displays.

[Contrast day] and **[Contrast night]** – Sets the screen settings for the day and night display.

[Set clock] – The clock can be set here by turning and pushing the menu knob if the time has not been taken over from the clock in the combi-instrument. The data for the arrival time is oriented towards this time if the route guidance function is active.

Note

The language can only be changed if the navigation CD has been inserted. ◀

External units

Calling up external units




Fig. 53 Main menu AUX

Calling up external units

– Press the key **AUX** ⇒ page 2, fig. 1 (14) to enter the AUX main menu.

Function keys in the AUX main menu

AV (A/V) – switches over to an external audio (A) or video (V) source.

AUX – Switches to an audio unit which is connected to the system.

Settings – Settings for the units connected to the system:

- **A+V:** The unit AV1 or AV2 delivers audio and video signals (sound and picture).
- **AUDIO:** The unit delivers audio signals only.
- **VIDEO:** The unit delivers video signals only.
- **OFF:** There is no unit connected. ◀

Index

A

Allocating the radio stations
Radio 8
AM
Medium wave 7
Announcements 35
AS 6
Autozoom 31
AUX 38
AV 38

B

Back / Forwards
Radio station selection 8
Balance 14
Blocking stretches of the journey 28

C

CD 9
Ejection 10
Fast forward/reverse 9
Playing a CD from the CD changer 13
CD changer
CD slot 11
CD slots 11
Displays 12
EJECT 11
Ejecting a CD 11, 12
Ejecting all CDs 12
Fast loading 12
Load 11
Loading 12
Loading CD slots 12
Operation 12
Overview 11
Status displays 11
CD changer and radio mode
Selecting a CD 12
Control elements 2
Controls
CD changer 11
Coordinates 22
Crosshair 22

D

Day/night display 37
Default settings 14
Delete
Destinations in the destination memory 25
Last destinations 20
Letters, symbols, numbers 19
Demonstration 27
Destination 18
Renaming 24
Sorting 24
Storing 23
Destination entry 18
Destination memory 21
Destination on the map 22
Intersection, centre 19
Last destinations 20
Position destination 22
Special destinations 21
Town, street, house number 19
Destination memory 23

E

Ejecting a CD 11
ESC 3
External CD changer
CD changer 11

F

Factory settings 14
FM
VHF 7
Function keys 2

G

GALA 14

I

INFO 36
Information 36

Initial Autostore 7

K

Keys

Quick reference guide 2

L

Language setting 37

Last destinations 20

Latitude 22

List of stations 8

Location 27

Longitude 22

M

Main menu

AUX 38

AV 38

CD 9

Navigation 17

Radio 6

Sound 14

MAP 29

Map

Alignment 31

Map contents 32

Map display 29

Display options 30

Map section 31

Map type 30

Menu knob 2

Mix 10

Muting

Navigation recommendations 14

Radio 7

N

Navigation 15

Navigation CD 16

Navigation recommendations 35

O

Operation

Multi-function buttons (CD changer) 12

P

Parameters for route calculation 26

Position 27

Position display 33

Q

Quick reference guide 2

R

Radio 6

Muting 7

Radio station selection 8

From list 8

RDS 9

Route guidance 27, 34

Route list 32, 36

Route options 26

S

Safety code 5

Scale 30

Scan 10

Radio stations 6

Screen

Darkened 3

Setting the clock 37

Settings

Radio 6

Settings at time of delivery 14

Software version 36

Sound 14

Special characters 19

Spoken announcements 36

Station buttons 3

Status bar 4

Stopover destination 18

Switching off 5

Switching on 5

Switch-on volume 14

Symbol display 30

System info 36

System settings 37

T

Text reports 36

TIM 36

Time format 31

Traffic

Text announcements 31

Traffic information reports 7

Traffic jam function 28

Traffic reports

Spoken announcements 36

U

Unit card 5

V

Video 38

Volume 14

W

Waveband

Setting 7



Afterword

Volkswagen AG works continuously to develop and further improve all models. Please appreciate that we must therefore reserve the right to alter any part of the vehicle and its equipment or technical specifications at any time. No legal commitment can therefore be derived from the information, illustrations or descriptions in this manual.


No part of this manual may be reprinted, reproduced or translated without the written permission of Volkswagen AG.

The texts, illustrations and standards in this manual are based on the information available at the date of publication.

All rights under the laws of copyright are expressly reserved by Volkswagen AG. Subject to alteration and amendment.

Printed in Germany

© Volkswagen AG

 **For the sake of the environment**

This paper was bleached without the use of chlorine.